Adjustments and Evolution Stages of Channel **Evolution** Examples from Vermont STABLE Original Floodplain INCISION WIDENING New STABILIZING STABLE